



Samsung Gear S2 Bezel Replacement

Does the bezel no longer switch between applications and scroll? Replace it using this guide.

Written By: Jacob Baldwin



INTRODUCTION

Does spinning the bezel no longer cause the watch to scroll? Replacing the bezel may solve the problem.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Bezel



- Insert a plastic opening tool under the bezel, and then pry the bezel up.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-30 05:59:02 AM.